



## Stone chip repair UV



### SCU 20

Fast UV curing clear coat for stone chip and scratch repair

Fast, simple and cost effective repair of stone chips and scratches  
 1-component, fast curing  
 No shrinkage after curing  
 High level of finish  
 Same strength, durability and chemical resistance as a 2K clear coat  
 Can be sanded and polished after 45 seconds  
 Curing with stone chip curing lamp SCL 00

The perfect stone chip repair in 10 easy steps :

- 1 Clean/degrease the surface with TSP 600 Foam-it!
- 2 Sand around the stone chip with SPDM P1500-2000
- 3 Clean with TSP 600 Foam-it!
- 4 Apply the base coat
- 5 Dry the base coat
- 6 Apply stone chip repair UV with PMP touch-up tips
- 7 Dry for 45 seconds at 20mm. distance with stone chip curing lamp
- 8 Remove excess clear coat with DRF 10 dust removal file
- 9 Sand with SPDR P1500-2000
- 10 Polish with Finixa polishing system



Code	Description	Box	Pal
SCU 20	UV stone chip repair - 20g	12	X

